Miele

Operating and Installation Instructions



Oven
H 4680 B

en - US, CA

To prevent accidents
and machine damage,
read these instructions
before installation or use.

M.-Nr. 06 426 230

Contents

IMPORTANT SAFETY INSTRUCTIONS 4
Guide to the oven 7
Guide to the display 8
Oven accessories 9
Baking tray, roasting pan, wire rack 9
Grease filter 10
Roast probe 10
Slide opener 10
Locking the oven 11
Using the system lock: 11
Using the oven display 12
SETTINGS 13
Language 14
Clock 14
Temperatures 15
Oven Light 16
Temperature °F / °C 16
Tone Options 17
Display 18
Reset 19
System lock 19
Before using the oven 20
Using the oven 22
Selecting a function 22
Adjusting the oven temperature 22
Preheating 23
Delay Start 23
Duration 23
Start time 24
End time 24
Canceling a process 25
Turning off the oven 25
At the end of cooking: 25
Setting the timer 26

Contents

Guide to the functions . . . 27
BAKE . . . 29
Baking tips . . . 29
ROAST . . . 34
Roasting tips . . . 37
Using the roast probe . . . 38
MASTER CHEF . . . 41
BROIL . . . 44
Broiling tips . . . 47
FAVORITES . . . 48
SABBATH . . . 49
DEHYDRATE . . . 50
PROOF . . . 51
DEFROST . . . 52
Defrosting tips . . . 52
Cleaning . . . 53
PerfectClean . . . 54
Removing the oven door . . . 56
Removing the runners . . . 59
Removing the back panel . . . 60
Removing the ceiling panel . . . 60
Catalytic liners . . . 61
Changing the light bulb . . . 62
Frequently asked questions . . . 64
Technical Service . . . 65
Optional accessories . . . 66
Installation instructions . . . 69
Caring for the environment . . . 70
Disposal of the packing materials . . . 70
Disposal of an old appliance . . . 70
Electrical connection . . . 71
Appliance and Cut-out Dimensions . . . 72
Installing the oven . . . 73

Preview Limit Reached! To view more of this manual, please visit:
http://freemanualdownload.com/Miele-H4680B-free-manual-download